




Installation Instructions


i720[®]



Preparation of the Work Area:


- Please read through entire instructions before installation.
- Make sure the width and depth of the joint face are 90 ° to the slab's surface.
- Measure along length of joint to ensure opening is correct size for joint material.
- Remediate deviations that exceed product tolerances.
- To ensure successful installation, clean the blockout/joint edge of all contaminants and impurities

Installation Instructions Steps:




1. Install the architectural joint system on the wall
2. Cut the aluminum variable degree retainer and plate components to the desired length


3. Measure the wall height and cut the back seal to length, making it slightly longer than required. Install seal in one continuous piece. Starting at the top of the joint, insert the seal lugs into the frame receptacles




4. Trim excess length of the backseal at the base of the wall

Note: Extend the back seal to the ground, keeping it longer than the visual face seal. This will allow for moisture trapped between the seals to escape






7. Depending upon the project requirements, a continuous bead of caulk (by others) may be required to be installed where the outside edge of the face seal abut the substrate walls



5. Cut the face seal to a length slightly longer than required. Install the face seal as a continuous piece. Starting at the top of the joint, push the seal lugs into the frame receptacles
6. Trim the excess length at the base of the wall



8. Per project dictates, address details at the top of the wall where the system meets with the expansion joint on the roof or roof parapet

Note: for inside corners or restricted gap access, frames may be secured in place with contractor furnished epoxy adhesive instead of mechanical fasteners

