

- Preparation of the Work Area

1. Please read through entire instructions before installation.
2. Make sure the width and depth of the joint face are 90° to the slab's surface.
3. Measure along length of joint to ensure opening is correct size for joint material. Remediate deviations that exceed product tolerances.
4. To ensure successful installation, clean the blockout/joint edge of all contaminants and impurities.

1. Cut the aluminum components to the desired length..
2. Place the frames firmly against the curb with the radius profile of the frames facing the structural gap.
3. Reference project details to verify final frame position
4. Mark the pre-drilled hole locations on the curb and
5. Return the frames into position over the drilled hole locations.
6. Slide the vinyl gasket into the top of the frame's.
7. Return the frame assembly into position over the drilled hole locations.
8. Place the plate assembly centered over the frames. Tighten the screws to engage the centerbar in the frame channels.
9. Clean exposed surface with non-solvent cleaner.

