

- Preparation of the Work Area

1. Please read through entire instructions before installation.
2. Make sure the width and depth of the joint face are 90° to the slab's surface.
3. Measure along length of joint to ensure opening is correct size for joint material. Remediate deviations that exceed product tolerances.
4. To ensure successful installation, clean the blockout/joint edge of all contaminants and impurities.
 1. Cut the aluminum frames to the desired length.
 2. Secure the frames to the tees with pop rivets .
 3. Press the Santoprene seal into the recessed slots of the frames until the seal is flush with the bottoms of the frames.
 4. Install ceiling tiles and clean the exposed surfaces with a non-solvent cleaner.

